

Assembly Instructions for Timber Triangle Arch

Tools Required:

- Phillips Head Screwdriver and/or Screw Gun
 - Tent Pegs or Weights (for outdoor use)
 - *Recommended: 2 people for assembly and setup*
 - *Product installation videos are available on the product listing in our website*
-

Step 1: Organize the Parts

1. Lay all parts of the arch on the floor.
 - Start with **A** at the top, followed by **B**, and then **C** at the base plate.
-

Step 2: Assemble the Sides

1. Take one side of the arch (e.g., left side).
 2. Use **4 bolts and barrels** to connect parts **A** and **B**.
 3. Next, use **4 bolts and barrels** to connect parts **B** and **C**.
 4. Repeat this process on the opposite side to assemble the second side.
-

Step 3: Join the Top

1. Align the two **A** parts at the top of the arch.
 2. Use bolts and barrels to securely connect them, forming the triangular shape.
-

Step 4: Attach the Base Plates

1. Place the **base plates** on either side of part **C** (one on the left and one on the right).
 2. Stand the arch into the slots on the base plates (*assistance may be needed for this step*).
-

Step 5: Secure the Base Plates

1. Using the brackets and **4 screws**, attach part **C** to the base plate on one side.

2. Repeat the process on the other side of part **C**.
3. Repeat steps 1 and 2 for the opposite side of the arch, securing all **4 brackets**.

Step 6: Stabilize the Arch

1. For outdoor use, secure the arch to the ground using **tent pegs** or **weights**.
 - *Important: Outdoor use is not recommended in windy conditions.*
-

Additional Notes:

- This arch is recommended for **indoor use**.
- Lightweight construction is ideal for **light floral arrangements** and fabric draping.
- Ensure all bolts, barrels, and screws are tightened securely during assembly.
- To disassemble for transit, remove the bolts between parts A & B, allowing transport in 3 parts.

